

Addendum 1: Actuator Support Installation on a MOOSE PLOW

Adapter Block: Part Number 1064 (2) Required

1. Disconnect the plow from the ATV at the push tube assembly, per the manufacturer's instructions.
2. Tip plow to gain access to the underside of the plow angle adjustment assembly.
3. Remove and discard the lift bar and M8-1.25x40mm bolt and nut.
4. Remove and discard the (4) M8-1.25x20mm bolts and nuts that secure the plow angle adjustment assembly.
5. Place adapter blocks 1064 on top of the vacant holes in the blade positioning lever mounting bracket.
6. Remove (4) 3/8-16x1.5" bolts and jam nuts previously installed on the lower actuator support in section A, step 8 of the installation instructions. Discard bolts and nuts.
7. Secure actuator support using (4) 5/16-24x2" flanged bolts and (4) 5/16-24 Nylock nuts.
8. Reconnect the plow to the ATV and install the actuator as discribed in step "C" of the instructions.



