

Addendum 6: Actuator Support Installation on a WEEKEND WARRIOR PLOW

Adapter Plate: Part Number 1049

1. Disconnect the plow from the ATV at the push tube assembly, per the manufacture's instructions.
2. Tip plow to gain access to the underside of the plow angle adjustment assembly.
3. Remove the (2) 1/2-13x2" bolts that secure the lifting bracket. Discard the lifting bracket, (1) bolt, and (1) nut.
4. Remove the (2) 1/2-13x2" bolts that secure the blade positioning pin assembly and retain for future use.
5. Remove the (4) 3/8-16x1.5" bolts on the actuator support angles.
6. Secure the assembled actuator support to the adaptor plate using (4) 3/8-16x1.5" bolts just removed and (4) 3/8-16 Nylock nuts.
Note: Bolts must be installed thru the underside of the adaptor plate and nuts on the top of the actuator support angles.
7. Secure the assembled actuator support / adaptor plate to the plow angle adjustment assembly using (3) 1/2-13x2" bolts, and (3) 1/2-13 lock nuts retained in steps 3 and 4.
8. Reconnect the plow to the ATV and install the actuator as discribed in step "C" of the instructions.

Adapter Plate Part Number 1049







